

Mixing, Placing, and Finishing

LOADING FIBERS WITH CONVEYOR



CONCRETE BEING TRUCK DUMPED



LOADING FIBERS ON PLATFORM



CONCRETE BEING PUMPED



Steel fibers can be added before during or after the concrete has been added to the truck. The fiber must mix for 3-4 minutes. Steel fibers are compatible with most admixtures. Calcium chloride should not be used with any steel product.

Steel fiber reinforced concrete can be handled by any means. Steel fiber reinforced concrete does not require any special procedures.

Mixing, Placing, and Finishing

LASERSCREED AND FIBERS THE PERFECT COMBINATION



SOFFCUT SAW



SFRC BEING FINISHED WITH PANS



THE FINISHED JOINT



BROOM FINISH AND TOOLING JOINTS



Mixing, Placing, and Finishing

FINISHED POLISHED FLOOR



FINISHED STEEL COIL FACILITY



FINISHED STEEL PROCESSING PLANT



FINISHED DISTRIBUTION FLOOR



FINISHED FLOOR AT THOMAS BUS

